



DO NOT OVER TIGHTEN

*When fitting the filter to its counterpart please ensure you do **not** over tighten the hose clamp connecting them.*

Doing so could result in the part being crushed, leading to fitment and/or performance issues.

*The recommended torque setting for this hose clamp is **2-2.4Nm***

